

Legato Assembly Guide

Flat Blade Post - Surface Mount - Spider Clips - End Post

- 1. Plumbing Legato Post.** Before completing attachment of Legato post/posts to substrate - take all necessary steps to assure that the mounted post/posts are adjusted such that the post/posts are plumb to 1/16" at an extended height of 42". Spend the time required to plumb the post/posts to this tolerance to ensure correct alignment of all components.
- 2. Decorative Flange Cover.** Decorative flange cover is supplied already mounted to post (1).
- 3. Install Spider Clips.** Disassemble spider clip assembly by separating part (2) from main clip body. Discard coped adapter provided with assembly - this is not used. Take countersunk head screw (3) and locate in pre-drilled countersunk hole in post (1). Slide round disk (2) over countersunk screw (3). Take remaining main spider arm assembly and wind onto exposed thread of countersunk screw ensuring glass clamping arm of fitting is horizontal to finished floor surface.
- 4. Install Glass Infill Panel.** Remove countersunk fixing screw (6) and circular metal disk, black circular gaskets and plastic tubular isolation grommet. Repeat process for all spider clips. Have someone hold the glass panel in place between the spider clips. Make sure a circular black gasket is located between the glass and inner circular spider clip pressure plate. Place tubular plastic grommet in hole within glass panel. Place second circular black gasket and circular outer pressure disk onto face of glass. Pass countersunk screw (6) through hole in outer disk, thru hole in glass and tighten (10-15ft-lbf torque) into main spider clip body. Ensure infill panel is level.
- 5. Install Hand Rail.** Place handrail on top of saddle bracket/brackets and temporarily secure in place. Using pre-drilled holes in saddle bracket mark handrail. Drill handrail and secure to saddle bracket (3) using a #10 sheet metal screw (Not included)

